

Service Tips

Modification of Fahrenheit to Celsius



Applies to remote control models:
 AR-RY7, AR-RY6, AR-RY5, AR-RY16, AR-RY15, AR-RAH2U, UTY-LNHUM,
 UTY-RAE2U, AR-RAH1U


To convert the Inverter wireless remote control from Fahrenheit to Celsius, jumper 5 would need to be removed.



Remove all screws from behind the remote control and open up.



To make the conversion, remove the number 5 jumper from the remote's circuit board.



Reassemble in reverse order to put the remote back together.